

Настройка IPTV в роутерах D-link DI-524UP, DI-604UP, DI-624, DI-624S

Перед настройкой функции multicast необходимо обновить прошивку маршрутизатора до последней версии.

Необходимо зайти в меню в меню web-интерфейса: *Tools > Misc* и выбрать «**Multicast streaming Enabled**».

Затем нажмите «**Apply**».

The screenshot shows the web interface of a D-link DI-524UP router. The left sidebar contains navigation buttons: Admin, Time, System, Firmware, Misc. (highlighted in yellow), and Cable Test. Below these is a language dropdown menu set to English. The main content area has a top navigation bar with tabs: Home, Advanced, Tools (selected), Status, and Help. Under the 'Tools' tab, there are several sections: 'Ping Test' with a text input for 'Host Name/ IP Address' and a 'Ping' button; 'Block WAN Ping' with a description and radio buttons for 'Enabled' and 'Disabled' (selected); 'SPI mode' with a description and radio buttons for 'Enabled' and 'Disabled' (selected); 'Multicast streaming' (highlighted with a red box) with a description and radio buttons for 'Enabled' and 'Disabled' (selected); 'UPnP Settings' with a description and radio buttons for 'Enabled' and 'Disabled' (selected); 'VPN Pass-Through' with a description and radio buttons for 'Enabled' and 'Disabled' (selected); and 'WAN select to 10/100 Mbps' with radio buttons for '100Mbps', '10Mbps', and '10/100Mbps Auto' (selected). At the bottom right, there are three icons: a green checkmark, a yellow 'X', and a red plus sign, with labels 'Apply', 'Cancel', and 'Help' respectively.