

ASUS Wireless Router

ASUS Home Gateway

- Home
- Quick Setup
- Wireless
- IP Config
 - WAN & LAN
 - IPv6
 - SNMP
 - DHCP Server
 - Route
 - Miscellaneous
- NAT Setting
- Internet Firewall
- USB Application
- Bandwidth Management
- System Setup
- Status & Log
- Logout

IP Config - WAN & LAN

WL500g.PremiumV2 supports several connection types to WAN. These types are selected from the drop-down menu beside WAN Connection Type. The setting fields will differ depending on what kind of connection type you select.

WAN Connection Type:	L2TP
WAN Connection Speed:	Auto negotiation

WAN IP Setting

Get IP automatically?	<input type="radio"/> Yes <input checked="" type="radio"/> No
IP Address:	ваш IP из договора
Subnet Mask:	255.255.255.0
Default Gateway:	Основной шлюз

WAN DNS Setting

Get DNS Server automatically?	<input type="radio"/> Yes <input checked="" type="radio"/> No
DNS Server1:	10.221.0.50 ДНС1
DNS Server2:	10.221.10.100 ДНС2

PPPoE, PPTP or L2TP Account

User Name:	Ваш логин
Password:	Ваш пароль
Idle Disconnect Time in seconds(option):	0 <input type="checkbox"/> Tx Only
MTU:	
MRU:	
Service Name(option):	
Access Concentrator Name(option):	
PPTP Options:	No Encryption
Additional pppd options:	
Enable PPPoE Relay?	<input type="radio"/> Yes <input checked="" type="radio"/> No

Special Requirement from ISP

Host Name:	
MAC Address:	
Heart-Beat or PPTP/L2TP (VPN) Server:	l2tp.azimut-r.ru